## Service Letter

## Hunan Sunward Aircraft Co.,Ltd.

S/N:SL-2023-SA60L-06

Ver.(Version):01

Date:26th Apr. 2023

Title Requirements for replacement of brake system three-way connectors.  Type Standard  Scope of Application This service letter is applicable to the Aurora SA60L series and Aurora SA70L series light sport aircraft listed in Attachment 1.  For the Aurora SA60L series and Aurora SA70L series light sport aircraft, there is a soft hose connecting the bottom interface of the brake fluid cup to the three-way connector. Under certain external pulling force, it may come off. Therefore, we have selected a higher fastening level three-way connector, which needs to be replaced for all applicable aircraft according to the requirements. Effective date.:2023.4.26 Date of issuance:2023.4.26  1.The replacement operation steps are as follows.  1) Refer to Chapter 5.3.6 of the "SWT/JYF101014A90, Maintenance Manual", and perform brake fluid discharge until it reaches the appropriate liquid level height that does not affect the replacement of the connector.  2) Replace the single-ear stepless hose clamp, connecting pipe, tee joint, and brake fluid cup sealing ring shown in the figure below.  Connecting pipe  Brake fluid cup  E接管  Eil接头
This service letter is applicable to the Aurora SA60L series and Aurora SA70L series light sport aircraft listed in Attachment 1.  For the Aurora SA60L series and Aurora SA70L series light sport aircraft, there is a soft hose connecting the bottom interface of the brake fluid cup to the three-way connector. Under certain external pulling force, it may come off. Therefore, we have selected a higher fastening level three-way connector, which needs to be replaced for all applicable aircraft according to the requirements.  Effective date.:2023.4.26 Date of issuance:2023.4.26  1.The replacement operation steps are as follows.  1) Refer to Chapter 5.3.6 of the "SWT/JYF101014A90, Maintenance Manual", and perform brake fluid discharge until it reaches the appropriate liquid level height that does not affect the replacement of the connector.  2) Replace the single-ear stepless hose clamp, connecting pipe, tee joint, and brake fluid cup sealing ring shown in the figure below.  Connecting pipe  E接管  Alse fluid cup
Reason  Reaso
For the Aurora SA60L series and Aurora SA70L series light sport aircraft, there is a soft hose connecting the bottom interface of the brake fluid cup to the three-way connector. Under certain external pulling force, it may come off. Therefore, we have selected a higher fastening level three-way connector, which needs to be replaced for all applicable aircraft according to the requirements.  Effective date.:2023.4.26 Date of issuance:2023.4.26  1.The replacement operation steps are as follows.  1) Refer to Chapter 5.3.6 of the "SWT/JYF101014A90, Maintenance Manual", and perform brake fluid discharge until it reaches the appropriate liquid level height that does not affect the replacement of the connector.  2) Replace the single-ear stepless hose clamp, connecting pipe, tee joint, and brake fluid cup sealing ring shown in the figure below.  Brake fluid cup  E接管  A 车油杯  Eilek头
a soft hose connecting the bottom interface of the brake fluid cup to the three-way connector. Under certain external pulling force, it may come off. Therefore, we have selected a higher fastening level three-way connector, which needs to be replaced for all applicable aircraft according to the requirements.  Effective date.:2023.4.26 Date of issuance:2023.4.26  1.The replacement operation steps are as follows.  1) Refer to Chapter 5.3.6 of the "SWT/JYF101014A90, Maintenance Manual", and perform brake fluid discharge until it reaches the appropriate liquid level height that does not affect the replacement of the connector.  2) Replace the single-ear stepless hose clamp, connecting pipe, tee joint, and brake fluid cup sealing ring shown in the figure below.  Brake fluid cup  E接管  E通接头
connector. Under certain external pulling force, it may come off. Therefore, we have selected a higher fastening level three-way connector, which needs to be replaced for all applicable aircraft according to the requirements.  Effective date.:2023.4.26 Date of issuance:2023.4.26  1.The replacement operation steps are as follows.  1) Refer to Chapter 5.3.6 of the "SWT/JYF101014A90, Maintenance Manual", and perform brake fluid discharge until it reaches the appropriate liquid level height that does not affect the replacement of the connector.  2) Replace the single-ear stepless hose clamp, connecting pipe, tee joint, and brake fluid cup sealing ring shown in the figure below.  Brake fluid cup  E接管  E通接头
have selected a higher fastening level three-way connector, which needs to be replaced for all applicable aircraft according to the requirements.  Effective date.:2023.4.26 Date of issuance:2023.4.26  1.The replacement operation steps are as follows.  1) Refer to Chapter 5.3.6 of the "SWT/JYF101014A90, Maintenance Manual", and perform brake fluid discharge until it reaches the appropriate liquid level height that does not affect the replacement of the connector.  2) Replace the single-ear stepless hose clamp, connecting pipe, tee joint, and brake fluid cup sealing ring shown in the figure below.  Brake fluid cup  连接管  连接管  正通接头
have selected a higher fastening level three-way connector, which needs to be replaced for all applicable aircraft according to the requirements.  Effective date.:2023.4.26 Date of issuance:2023.4.26  1.The replacement operation steps are as follows.  1) Refer to Chapter 5.3.6 of the "SWT/JYF101014A90, Maintenance Manual", and perform brake fluid discharge until it reaches the appropriate liquid level height that does not affect the replacement of the connector.  2) Replace the single-ear stepless hose clamp, connecting pipe, tee joint, and brake fluid cup sealing ring shown in the figure below.  Connecting pipe  E接管  Africant Agriculture (Agriculture) (Agriculture
1. The replacement operation steps are as follows.  1) Refer to Chapter 5.3.6 of the "SWT/JYF101014A90, Maintenance Manual", and perform brake fluid discharge until it reaches the appropriate liquid level height that does not affect the replacement of the connector.  2) Replace the single-ear stepless hose clamp, connecting pipe, tee joint, and brake fluid cup sealing ring shown in the figure below.  Brake fluid cup 连接管
1.The replacement operation steps are as follows.  1) Refer to Chapter 5.3.6 of the "SWT/JYF101014A90, Maintenance Manual", and perform brake fluid discharge until it reaches the appropriate liquid level height that does not affect the replacement of the connector.  2) Replace the single-ear stepless hose clamp, connecting pipe, tee joint, and brake fluid cup sealing ring shown in the figure below.  Connecting pipe  Brake fluid cup  连接管  连接管
1) Refer to Chapter 5.3.6 of the "SWT/JYF101014A90, Maintenance Manual", and perform brake fluid discharge until it reaches the appropriate liquid level height that does not affect the replacement of the connector.  2) Replace the single-ear stepless hose clamp, connecting pipe, tee joint, and brake fluid cup sealing ring shown in the figure below.  Connecting pipe  Brake fluid cup  连接管  三通接头
and perform brake fluid discharge until it reaches the appropriate liquid level height that does not affect the replacement of the connector.  2) Replace the single-ear stepless hose clamp, connecting pipe, tee joint, and brake fluid cup sealing ring shown in the figure below.  Connecting pipe  Brake fluid cup  连接管  三通接头
height that does not affect the replacement of the connector.  2) Replace the single-ear stepless hose clamp, connecting pipe, tee joint, and brake fluid cup sealing ring shown in the figure below.  connecting pipe  连接管
2) Replace the single-ear stepless hose clamp, connecting pipe, tee joint, and brake fluid cup sealing ring shown in the figure below.  Connecting pipe  连接管  到车油杯  三通接头
brake fluid cup sealing ring shown in the figure below.  Connecting pipe  连接管  到车油杯  三通接头
Brake fluid cup 连接管  三通接头
Brake fluid cup 连接管 刹车油杯 三通接头
刹车油杯
刹车油杯
三通接头
Execution 单耳无极卡箍 tee joint
Execution
Requirements. single-ear stepless hose clamp
3) After the replacement is completed, refer to Chapter 5.3.6 of the
"SWT/JYF101014A90, Maintenance Manual" and perform brake fluid filling.
2. List of removed components.
No. Item Number Item Description Qty
1 730120000279 Equal diameter to variable diameter 1
T-shaped tee PEN6-10-6
2 712052990008 Transparent silicone tubeTP9X1.5 0.2meters
3 701901010001J Stainless steel single ear stepless 1
clamp 100.
clamp 100. 4 730699000001J Brake fluid cup D42 seal ring. 1

	Replacement part list.								
	No.	Item Number	Item Description	Qty					
	1	7330000029	T-shaped three-way connector.	1					
	2	712052990008	Transparent silicone tubeTP9X1.5	0.2meters					
	3	701901010001J	1						
			clamp 100.						
	4	730699000001J	Brake fluid cup D42 seal ring.	1					
	3.After completion, record it in the "Service Letter Execution Record" section of								
	the aircraft logbook corresponding to the aircraft's serial number.								
Reference	SWT/JYF101014A90 09Version Maintenance manual.								
Equipment	Phillips screwdriver, 11mm open-end wrench, 13mm open-end wrench, single ear								
Equipment	hose clamp pliers.								
Weight and	No Influence								
Balance									
Specialized	None								
Tools and									
Equipment.									
Contact Person:Peng Liang									
Phone:86-15974184415 Fax:4006635288 E-mail:safety@sunward.cc									
Date:2023.4.26									
Project leader's signature:Zhou Zhidong									

Attachment 1.

Related document: SL-2023-SA60L-06 Brake System Tee Joint Replacement Requirements.

Title	Applicable Aircraft List for Brake System Tee Joint Replacement.									
No.	Serial Number	No.	Serial Number	No.	Serial Number	No.	Serial Number	No.	Serial Number	
1	SA60LS00218	27	SA60LS00248	53	SA60LS00280	79	SA60LS00315	105		
2	SA60LS00219	28	SA60LS00249	54	SA60LS00281	80	SA60LS00317	106		
3	SA60LS00220	29	SA60LS00251	55	SA60LS00282	81	SA60LS00318	107		
4	SA60LS00221	30	SA60LS00252	56	SA60LS00283	82	SA60LS00319	108		
5	SA60LS00222	31	SA60LS00253	57	SA60LS00285	83	SA60LS00320	109		
6	SA60LS00223	32	SA60LS00255	58	SA60LS00286	84	SA60LS00321	110		
7	SA60LS00225	33	SA60LS00256	59	SA60LS00287	85	SA60LS00322	111		
8	SA60LS00226	34	SA60LS00257	60	SA60LS00288	86	SA60LS00325	112		
9	SA60LS00227	35	SA60LS00258	61	SA60LS00290	87	SA60LS00327	113		
10	SA60LS00228	36	SA60LS00259	62	SA60LS00291	88	SA70LS00102	114		
11	SA60LS00230	37	SA60LS00260	63	SA60LS00292	89	END	115		
12	SA60LS00231	38	SA60LS00261	64	SA60LS00293	90		116		
13	SA60LS00232	39	SA60LS00262	65	SA60LS00295	91		117		
14	SA60LS00233	40	SA60LS00263	66	SA60LS00296	92		118		
15	SA60LS00235	41	SA60LS00265	67	SA60LS00301	93		119		
16	SA60LS00236	42	SA60LS00266	68	SA60LS00302	94		120		
17	SA60LS00237	43	SA60LS00267	69	SA60LS00303	95		121		
18	SA60LS00238	44	SA60LS00268	70	SA60LS00305	96		122		
19	SA60LS00239	45	SA60LS00269	71	SA60LS00306	97		123		
20	SA60LS00240	46	SA60LS00270	72	SA60LS00307	98		124		
21	SA60LS00241	47	SA60LS00271	73	SA60LS00308	99		125		
22	SA60LS00242	48	SA60LS00272	74	SA60LS00309	100		126		
23	SA60LS00243	49	SA60LS00273	75	SA60LS00310	101		127		
24	SA60LS00245	50	SA60LS00275	76	SA60LS00311	102		128		
25	SA60LS00246	51	SA60LS00276	77	SA60LS00312	103		129		
26	SA60LS00247	52	SA60LS00277	78	SA60LS00313	104		130		

Date: 2023.04.26

Signature of the authorized person from the manufacturing company(Stamp):Zhou Zhidong